

Installation Guide

Ledger Stone Collection

Technical Specs

- 100% natural stone surface
- Interior and exterior applications
- Thickness: 1.5mm 2mm Sizes: 6"X24" Peel&Stick & Mesh Back
- 2'x 4, (mesh back only) Weight: approx. 0.32 - 0.35 lbs./ft.2

Recommended Products

Adhesive (Mesh Back Product)

- Titebond Advanced Polymer Panel Adhesive
- Interior:

Laticrete/Stonetech - Stone, Tile & **Grout Sealer**

Exterior/Shower Walls:

Laticrete/Stonetech - Heavy Duty Sealer or BulletProof Sealer

For installation assistance, please contact:

716.725.0208 or info@slimstoneusa.com

HOW TO CUT SLIMSTONE

BEFORE YOU START

Most patterns will require some cutting of the stone sheets. When cutting the stone, use long nosed hand snips, wet saw, table saw, or angle grinder. We suggest a diamond or carbide blade. All SlimStone products are easy to cut.

HOW TO INSTALL SLIMSTONE

Step 1: Measure & Clean Surface Area

Make sure substrate is free of dust/debris/oil. We recommend 15% overage for cuts

Step 2: Layout

Start from a level point, and draw start line for first row of stone veneer. If possible work from top to bottom of project.

Step 3: Prepare & Apply Adhesive (exterior mesh backed tiles only)

Use a notched trowel and apply adhesive to entire back of the stone sheet, leaving about ¼ inch around the corners for expansion.

Peel and Stick (interior use only)

Peel off back paper and apply to desired surface, stager pattern on each row. Due to differing environmental conditions with expansion and contraction with any natural product an individual stone might come slightly loose on the pressure sensitve glue. If this happen a general construction adhisive and be used to secure stone to

Step 4: Adhere Stone to Prepared Surface

Press firmly over the entire surface area with press block or roller.

Step 5: Apply Sealant

Apply waterbased sealant to entire stone surface area.

*Annual re-application of sealant is recommended

@ @slimstoneusa

https://slimstoneusa.com

298 Hinman Ave Buffalo, NY 14216